

950-254



# Bath Towel Holder

No. 202-398

## **BODYGUARD ASSEMBLY INSTRUCTIONS**

---

First, slide the bath-towel rod with the through holes on to the two hangers and secure these using the supplied set screws.

Then, do the same with the second tube and also secure it at both ends using the supplied set screws.

Hang your bath-towel holder from the shower partition and check that the bath-towel rods are parallel. Loosen the set screws to readjust if necessary.

## **CARE INSTRUCTIONS**

---

An occasional wipe with a damp chamois will be sufficient for the surfaces.

If necessary, a widely available liquid household agent may also be used.

Please do not use any scouring agents.

**D:** Pro-Idee GmbH & Co. KG · Auf der Hùls 205 · D 52053 Aachen · Tel.: 02 41-109 119  
**NL:** Pro-Idee · Toernooveld 300 · NL 6525 EC Nijmegen · Tel.: 024-3 511 277  
**UK:** Pro-Idee · Carriage House · Forde Road · Newton Abbot · TQ12 4EY · Tel.: 0844 557 1011  
**F:** Pro-Idée · F 67962 Strasbourg - Cedex 9 · Tél.: 03 88 67 22 77  
**CH:** Pro-Idee Catalog GmbH · Fürstenlandstrasse 35 · CH 9001 St. Gallen · Tel.: 0 71-2 74 66 19  
**A:** Pro-Idee Catalog GmbH · Bundesstraße 110 · A 6923 Lauterach · Tel.: 0810-900 698  
© Pro-Idee Aachen