



## Installation instructions

- 1. You need four holes in your wall; firstly you will attach the newspaper compartment with the provided dowel screws. (hole: 340 x 180 mm)
- 2. Subsequently you need to hang the mailbox in the newspaper compartment and let it slide downwards.
- 3. Inside the mailbox you now need to fasten two more screws, which you will find enclosed. (M6x16)
- 4. You can now lock your mailbox with the provided keys.
- 5. Done!

## Care instructions

- 1. Your mailbox is out of stainless steel. To prevent corrosion damages please avoid the permanent contact with other metals.
- 2. You can easily clean all powder coated mailboxes with a cotton cloth and water.
- 3. The mailbox out of polished stainless steel will thank you, if you clean it with a stainless steel cleaner a few times a year. Should there be a rust film because of unfavorable external influences, it can be removed through intensive rubbing.

