




## **Cardsharp**®

Item-no.: 204-338



Safety has priority. To prevent injuries but also to protect the cutting area, the blade is embedded in a precisely fitting depression in the handle. A unique locking mechanism keeps the blade safely in the casing. A knife with a fixed blade is then ready for use.

An additional benefit: through the exclusive use of non-rusting materials, the knife may be easily cleaned and in an "emergency" is also dishwasher-proof.



The green field indicates that the blade has been made safe.



Turning the safety with your thumb and index finger releases the blade and it can then be bent over.



Turn the blade by 180°.



Hold the blade and bend the small wing over.



Finally, fold the larger wing over the blade and smaller wing until the safety pins click fully into place.