


Place your "Clack" on top of the boiled egg and lift the steel ball.



Let the steelball go of and remove the "Clack" from the egg.



Remove the egg top by cutting into the resulted perforation, either with a knife or another suitable object.

TIP:

If the steel cap gets a firm grip on the egg after using, you can remove the egg top even without any other auxiliary instrument.

Design: Hartmut Dolp, Markus Roling, Volker Zitzmann