

951-644



Maserin Mushroom Knife

Item-no.: 211-171

Instructions for care and use

The blade of the mushroom knife is made of steel with high carbon content. In order to ensure the blade stays sharp for a long time, the knife should be cleaned by hand and dried after each use.

Careful

The blade of the knife is very sharp. You should be very careful when using the knife. The knife should not end up in the hands of children.

D: Pro-Idee GmbH & Co. KG · Auf der Hùls 205 · D 52053 Aachen · Tel.: 02 41-109 119

NL: Pro-Idee · Wijchenseweg 132 · NL 6538 SX Nijmegen · Tel.: 024-3 511 277

UK: Pro-Idee · Woodview Road · Paignton · TQ4 7SR · Tel.: 01803 677 916

F: Pro-Idée · F 67962 Strasbourg - Cedex 9 · Tél.: 03 88 67 64 55

CH: Pro-Idee Catalog GmbH · Fürstenlandstrasse 35 · CH 9001 St. Gallen · Tel.: 0 71-2 74 66 19

A: Pro-Idee Catalog GmbH · Bundesstraße 112 · A 6923 Lauterach · Tel.: 05574-803 51

© Pro-Idee Aachen