

# Art. no. 04002222

## COB wall light with switch



**HEITECH**<sup>®</sup>

Heitech Promotion GmbH  
Krefelder Strasse 562  
D-41066 Mönchengladbach  
Tel.: +49 (0)2161 47763-0  
Fax: +49 (0)2161 561746  
heitech-promotion.de

### Activating the batteries:

Remove the battery protection film. (Fig. 2)

### Inserting/changing the battery:

Open both battery covers.

Use three AAA batteries (observe the polarity).

Use Velcro or hang the COB wall light on a mop.

### Safety notice:

Keep out of the reach of children!

Do not look directly into the LED light!

Do not dispose of used electrical devices or batteries in household waste, please use official disposal points!



After the end of its service life, please take the device for proper disposal.

Do not throw in the household waste; take the device to a collecting point for electrical and electronic equipment.



The batteries included must be disposed of separately. In the interests of environmental protection, please also ensure appropriate recycling of the packaging materials.

Packaging materials are raw materials and can be recycled. Your responsible administration will be glad to provide details of the addresses and opening hours of collection points.

